



Parts List

FLOCO Gears

Page: 1 of 2
Effective: 01-Jan-15

DESCRIPTION	# OF TEETH	DIAMETER	PART NUMBER
Calibration Gear	16 Teeth	.375 DIA	9A-0020-1012C
Calibration Gear	17 Teeth	.375 DIA	9A-0020-1013C
Calibration Gear	18 Teeth	.375 DIA	9A-0020-1014C
Calibration Gear	19 Teeth	.375 DIA	9A-0020-1015C
Calibration Gear	18 Teeth	.460 DIA	9A-0020-1016C
Calibration Gear	19 Teeth	.460 DIA	9A-0020-1017C
Calibration Gear	20 Teeth	.460 DIA	9A-0020-1018C
Calibration Gear	21 Teeth	.460 DIA	9A-0020-1019C
Calibration Gear	22 Teeth	.460 DIA	9A-0020-1020C
Calibration Gear	23 Teeth	.460 DIA	9A-0020-1021C
Calibration Gear	24 Teeth	.460 DIA	9A-0020-1022C
Calibration Gear	21 Teeth	.570 DIA	9A-0020-1023C
Calibration Gear	22 Teeth	.570 DIA	9A-0020-1024C
Calibration Gear	23 Teeth	.570 DIA	9A-0020-1025C
Calibration Gear	24 Teeth	.570 DIA	9A-0020-1026C
Calibration Gear	25 Teeth	.570 DIA	9A-0020-1027C
Calibration Gear	26 Teeth	.570 DIA	9A-0020-1028C
Calibration Gear	27 Teeth	.570 DIA	9A-0020-1029C
Calibration Gear	28 Teeth	.570 DIA	9A-0020-1030C
Calibration Gear	21 Teeth	.670 DIA	9A-0020-1031C
Calibration Gear	22 Teeth	.670 DIA	9A-0020-1032C
Calibration Gear	23 Teeth	.670 DIA	9A-0020-1033C
Calibration Gear	24 Teeth	.670 DIA	9A-0020-1034C
Calibration Gear	25 Teeth	.670 DIA	9A-0020-1035C
Calibration Gear	26 Teeth	.670 DIA	9A-0020-1036C
Calibration Gear	27 Teeth	.670 DIA	9A-0020-1037C
Calibration Gear	28 Teeth	.670 DIA	9A-0020-1038C
Calibration Gear	29 Teeth	.670 DIA	9A-0020-1039C
Calibration Gear	30 Teeth	.670 DIA	9A-0020-1040C
Calibration Gear	31 Teeth	.670 DIA	9A-0020-1041C
Calibration Gear	32 Teeth	.670 DIA	9A-0020-1042C
Calibration Gear	33 Teeth	.670 DIA	9A-0020-1043C
Calibration Gear	34 Teeth	.670 DIA	9A-0020-1044C
Calibration Gear	35 Teeth	.670 DIA	9A-0020-1045C
Calibration Gear	36 Teeth	.670 DIA	9A-0020-1046C
Calibration Gear	37 Teeth	.670 DIA	9A-0020-1047C
Calibration Gear	26 Teeth	.770 DIA	9A-0020-1048C
Calibration Gear	27 Teeth	.770 DIA	9A-0020-1049C
Calibration Gear	28 Teeth	.770 DIA	9A-0020-1050C
Calibration Gear	29 Teeth	.770 DIA	9A-0020-1051C
Calibration Gear	30 Teeth	.770 DIA	9A-0020-1052C
Calibration Gear	31 Teeth	.770 DIA	9A-0020-1053C
Calibration Gear	32 Teeth	.770 DIA	9A-0020-1054C
Calibration Gear	33 Teeth	.770 DIA	9A-0020-1055C



Parts List

FLOCO Gears

Page: 2 of 2
Effective: 01-Jan-15

DESCRIPTION	# OF TEETH	DIAMETER	PART NUMBER
Calibration Gear	35 Teeth	.770 DIA	9A-0020-1057C
Calibration Gear	36 Teeth	.770 DIA	9A-0020-1058C
Calibration Gear	37 Teeth	.770 DIA	9A-0020-1059C
Calibration Gear	38 Teeth	.770 DIA	9A-0020-1060C
Calibration Gear	39 Teeth	.770 DIA	9A-0020-1061C
Calibration Gear	32 Teeth	.860 DIA	9A-0020-1062C
Calibration Gear	33 Teeth	.860 DIA	9A-0020-1063C
Calibration Gear	34 Teeth	.860 DIA	9A-0020-1064C
Calibration Gear	35 Teeth	.860 DIA	9A-0020-1065C
Calibration Gear	36 Teeth	.860 DIA	9A-0020-1066C
Calibration Gear	37 Teeth	.860 DIA	9A-0020-1067C
Calibration Gear	38 Teeth	.860 DIA	9A-0020-1068C
Calibration Gear	39 Teeth	.860 DIA	9A-0020-1069C
Calibration Gear	40 Teeth	.860 DIA	9A-0020-1070C
Calibration Gear	41 Teeth	.860 DIA	9A-0020-1071C
Calibration Gear	42 Teeth	.860 DIA	9A-0020-1072C
Calibration Gear	43 Teeth	.860 DIA	9A-0020-1073C
Calibration Gear	44 Teeth	.860 DIA	9A-0020-1074C
Calibration Gear	42 Teeth	.958 DIA	9A-0020-1076C
Calibration Gear	43 Teeth	.958 DIA	9A-0020-1077C
Calibration Gear	44 Teeth	.958 DIA	9A-0020-1078C
Calibration Gear	45 Teeth	.958 DIA	9A-0020-1079C
Calibration Gear	46 Teeth	.958 DIA	9A-0020-1080C
Calibration Gear	47 Teeth	.958 DIA	9A-0020-1081C
Calibration Gear	48 Teeth	.958 DIA	9A-0020-1082C

NOTE:

Drive Gear is always on the Worm (**Bottom**)
Driven Gear is always on the Register (**Top**)